


Fig 1.



English: Instructions for use of the *easy⁺ gametimer*

1	How to make your clock ready for use	4
2	How do you play with the <i>easy⁺ gametimer</i> .	4
3	How to temporarily pause the clock.	4
4	Starting a new game	4
5	Sound signal	4
6	Setting of the time measuring modes and time-controls	5
7	The time measuring modes of the <i>easy⁺ gametimer</i>	5
8	Changing of the settings during the game	6
9	How do you switch the <i>easy⁺ gametimer</i> off	6
	Technical specifications	6
	Warranty conditions	6


We wish to congratulate you on your decision to buy the *easy⁺ gametimer*.

The *easy⁺ gametimer* was developed in the Netherlands by Digital Game Technology BV, the designers of the official match clock of the World Chess Federation FIDE.


All information as regards the various digital game clocks by DGT can be found on our website: www.digitalgametechnology.com


We wish you a lot of playing pleasure with your *easy⁺ gametimer*.

1 How to make your clock ready for use


Take the *easy⁺ gametimer* out of the box and slide the battery cover open. Place 2 penlight batteries (AA, 1.5V) into the battery case. We would advise the use of alkaline batteries. Then close the battery cover. When your batteries become exhausted, the battery symbol  in the display will show (see Fig.1).

2 How do you play with the *easy⁺ gametimer*.


Switch the *easy⁺ gametimer* on by pressing on the On/Off button . The first time this is done, the default mode of the *easy⁺ gametimer* will show the "Game timer" method in which both players have 5 minutes 'count down' reflection time (see 6 and 7). The sound is switched on (see 5).

Press briefly on the central start/stop  button. The clock of the player whose lever is in the 'up' position starts counting down. After the player has made his move, he should press his lever and the 'count down' on the clock of his opponent begins.


3 How to temporarily pause the clock.

Count down of the clock can be temporarily be interrupted by pressing the central Start/Stop button . Press this button once more to restart the clock. During the pause the way the clock was set can be adapted (see 8).

4 Starting a new game

Press briefly on the On/Off button  and the *easy⁺ gametimer* is ready for a new game. The settings of the clock will be identical to the previous game.

5 Sound signal

You may switch the sound signal on or off at any time during the game by pressing the sound button . When sound is switched on, you will hear warning

beep signals during the last five seconds prior to falling of your flag.

6 Setting of the time measuring modes and time-controls

After the *easy*⁺ *gametimer* has been activated, you will notice the time-control and settings used during the last game. The time available to both players are surrounded by a blinking area. By pressing on the Start/Stop button **▶||**, you could start the game, but you may also first change the settings.

You now could:

Change the time available to both players simultaneously

Press on the **+** and/or the **-** button until the desired time appears in both displays. When you keep pressing the **+** and/or the **-** button, the time will change at an increased speed. The maximum time-limit is 9 hours and 59 minutes.

Please note: When time-control exceeds 20 minutes, you will see hours and minutes in the display. When there are less than 20 minutes left, you will see seconds as well.

Change time available to only one of the players

Move with the **<** and/or the **>** button through the display until the area of only the player whose time-limit you wish to change is blinking. Press on the **+** and/or the **-** button until the desired time appears in the display.

Change the time measuring mode

Move with the **<** and/or the **>** button through the display until the area around the time measuring modes is blinking. Press on the **+** and/or the **-**

button until the desired time measuring mode appears in the display.

Change the delay-time or the bonus-time per move (Only for the easy⁺ gametimer extra)

Move with the **<** and/or the **>** button through the display until the area around the extra time is blinking. Press on the **+** and/or the **-** button until the desired time appears in the display.

7 The time measuring modes of the easy⁺ gametimer

The *easy*⁺ *gametimer* gives you the option of timing your game in various ways.

Move timer

Each player has a certain amount of time available for each separate move. When a player has completed his move, he gets the allotted time available for his next move. When a player has used up his time for a move, the flag will appear in the display.

Game timer

Each player has a certain amount of reflection time for the entire game; the player decides for himself how he divides the time available for the game. When a player has used up his time, the flag will appear in the display. The clock will continue in the 'count up' mode. There will appear a **+** sign in the display.

Game timer count-up option

If you set the reflection time for both players on 0:00, then both times will at once switch to the 'count up' mode. After the clock is started, the time used by each player is recorded. There will appear a **+** sign in the display. No flag is then shown in the display.

Game timer + delay

This mode is the same as the 'Game Timer' mode. But each time the clock is pressed, the count down of the player to move is only activated after the delay-time has been used up.

Please note: When a player has used up all his time, the flag appears. The clock does not switch to the 'count up' mode.

Game timer + bonus

This mode is the same as the 'Game Timer' mode. But each time the clock is pressed, the remaining reflection time of the player is increased with the bonus time.

Please note: When a player has used up all his time, the flag appears. The clock does not switch to the 'count up' mode.

8 Changing of the settings during the game

You may change the settings of the **easy⁺ gametimer** during a game. Interrupt the operation of the time-controls by pressing the central Start/ Stop button **▶||**. Move with the **<** and/or the **>**, button through the display until the area around the setting you wish to change is blinking. Press on the **+** and/or the **-** button until the desired time or the desired time-control mode appears in the display. Please note: When you change the reflection time in which the hours and minutes are shown, the seconds digits of this time-mode will automatically switch to zero, without you being able to notice.

Restart now the proceedings of the game by pressing the central Start/ Stop button **▶||**.

9 How do you switch the easy⁺ gametimer off

You may switch off the **easy⁺ gametimer** by pressing the On/Off button **⏻** during one second. The settings

you were playing with are retained in the clock's memory.

Technical specifications

Batteries:	Penlight (AA, 1.5V), 2 pieces. Alkaline type recommended.
Service life:	By using 2 alkaline batteries and very regular use of your clock, you may count on a service life of at least 2 years.
Accuracy:	Better than one second per hour.
Cleaning:	Use a soft, almost dry cloth. Do not use abrasive cleaning agents.
Housing:	ABS synthetic material.

CE This DGT product complies to the regulations for electro magnetic compatibility 2004/108/EG.

Warranty conditions

DGT guarantees that your digital chess clock complies with the highest quality standards. If your **DGT easy⁺** – despite our care in choosing components and material, production and transport – nevertheless may show a defect during the first year after purchase, you should contact the agent who sold the appliance to you.

In order to qualify for this warranty on your new **DGT easy⁺**, you should present the warranty card (page 22) together with proof of purchase.

This condition of warranty is only validated if the **DGT easy⁺** has been used in a prudenial manner. Our obligations of warranty do not apply if attempts to

repair the clock have been carried out without our explicit permission in writing.